

Overview

A significant physical difference between Levelogger 6 and 5 Series dataloggers compared to all previous versions (including Edge and Gold Series), is one large optical eye/lens versus two smaller optical eyes and pin connection at the communication interface. As such, adaptors are available to ensure new and old Leveloggers are able to use all deployment and communication accessories.



The **L5/L6-Edge DRC Adaptor** (114261) allows the connection of Levelogger 6 and 5 Series dataloggers to previous versions of Direct Read Cables and Optical Adaptors. The **Edge-L5/L6 DRC Adaptor** (114262) allows the connection of Levelogger Edge/Gold Series dataloggers to Desktop Readers, Field Readers, Threaded and Slip Fit Adaptors, newer Direct Read Cables.

 Levelogger 6/5 Optical Eye/Lens	 Levelogger Edge/Gold Dual Optical Eyes	 117444 Mk3 USB-C PC Interface Cable	 118149 Desktop Reader (USB-C)	 114404 Desktop Reader 5 (USB)	 118148 Field Reader (USB-C)	 114403 Field Reader 5 (USB)	 Variable Part Numbers Direct Read Cable (6/5 Series)	 114630 114598 Threaded and Slip Fit Optical Adaptors	 109609 PC Interface Cable (USB)	 110149 Optical Reader with Dual Eyes (USB)	 Variable Part Numbers Direct Read Cable (Edge/Gold Series)	 112123 112706 Direct Read to Optical Adaptors (Edge/Gold Series)
 Levelogger 6/5 Series	 Levelogger Edge/Gold Series								 114261  Yes with L5/L6- Edge DRC Adaptor	 114261  Yes with L5/L6- Edge DRC Adaptor		
 114262  Yes with Edge- L5/L6 DRC Adaptor	 114262  Yes with Edge- L5/L6 DRC Adaptor	 114262  Yes with Edge- L5/L6 DRC Adaptor	 114262  Yes with Edge- L5/L6 DRC Adaptor	 114262  Yes with Edge- L5/L6 DRC Adaptor								

*Using an L5/L6-Edge DRC Adaptor with an older style optical reader will allow programming and diagnostic reporting, however, it will not allow data downloading from a 6 or 5 Series datalogger. In this case, a Desktop Reader or Field Reader must be used

Note: The L5/L6-Edge DRC and Edge-L5/L6 DRC Adaptors contain small, long-lasting batteries (not user-replaceable). The Adaptors should always be stored with caps on to prevent unnecessary battery drainage and protect the optical eye(s).